

President JFK-2A+

- Toets **CH 19/9** gedurende 3seconden ingedrukt houden om een keuze te maken tussen **Kanaal of Frequentie** uitlezing op de display.
- Toets **MEM** 3 seconden ingedrukt houden om de bandkeuze (BND) te wijziggen.

In de display knippert dan een van de letters A b C d E F g H I J.
Maak een keuze met de kanalenkiezer, voor de normale CB-band is dat **A**.

Keuze bevestigen door **MEM** toets 3 sec. ingedrukt te houden.

- Toets **AM/FM** toets kort indrukken om keuze te maken tussen AM/FM (voor Nederland is dat FM meest gebruikte)
- Controleer altijd of **RF Gain** en **Mic Gain** potmeters geheel open staan (rechtsom draaien).

+++++

- Push button **CH 19/9** during 3 seconds.
Select **Channel** or **Frequency** read out in the display.
- Push **MEM** during 3 seconds to change the selected Band (BND)
In the display blinks one of the letters of a band A b C d E F g H I J.
Use the channel selector to select the desired band.
The standard CB band is **A**.
Confirm the band by pushing **MEM** during 3 seconds.
- To select AM or FM, push the **AM/FM** button.
- Always check **RF Gain** and **Mic Gain**. These should be 'open', turn the potmeter to the right.